

How The *ISIMET* FLA Series Fire House System Works

1. Alarm Notification is received at the FLA Series Controller
2. Immediately ALL integrated devices are disabled and turned off.

**GAS RANGES - ELECTRIC OVENS
MICROWAVES - OUT DOOR GRILLS**

3. Alarm Notification is withdrawn.
The FLA Controller is now enabled but DOES NOT OPERATE
4. Service is restored only after-
"Manual" reset at the Panel.
5. Service is restored to the Kitchen Appliances only after MANUAL reset at the Panel. GAS Ranges and Electrical Appliances will now operate.
6. Service is restored to the REMOTE OPERATOR but this unit remains OFF until it is reset at the site.

Gas Service is only then restored to the Grill.

